



POWER CONTROLLER - Assembly STEP - 4

FINAL ASSEMBLY EXAMPLE BREAKER OPTION



***** DO NOT CONNECT POSITIVE
TERMINAL TO BATTERY AT THIS TIME *****



CORRECT BOOT POSITION OVER POWER TERMINALS



* ASSEMBLE POWER CONTROLLER AS SHOWN WITH BREAKER OR FUSE OPTION

* INSULATING BOOTS **MUST** BE USED ON AND **FULLY OVER** MAIN POWER TERMINALS