


# PowerMaster 9506 (427 FE) Starter

## STARTER - ALTERNATOR - BATTERY SWITCH

Powermaster 9506



BE SURE THAT EACH LOAD IS PROPERLY GROUNDED TO THE CHASSIS OR METAL PORTION OF BODY