

FACTORY FIVE '33 SYSTEM ASSIGNMENTS Ver 10.3

See www.isispower.com for standard Front Engine, Rear Engine, and Factory Five Racing GTM.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Fuel Pump and Sender Power	1	A	2	B	TRACK	4	LIGHT-BLUE	WHT-BLK
Reverse Lights	2	A	2	B	TRACK	5	WHITE	WHT-RED
Ignition*	3	A	1	B	TRACK	3	LIGHT-GREEN	WHT-BLU
Starter*	4	A	1	B	TRACK	4	LIGHT-BLUE	WHT-YEL
Headlights	5	A	1	B	TRACK: SOFT-START	5	WHITE	WHT-GRN
Front Parking lights	6	A	1	A	PWM	6	YELLOW	BLU-BLK
High beams	7	A	1	A	TRACK: SOFT-START	7	BLUE	BLU-RED
Heat and AC Starter	8	A	1	A	TRACK	8	GREEN	BLU-Lt BLU
Horn	9	A	1	A	TRACK	9	ORANGE	BLU-YEL
Cooling Fan	10	A	1	A	TRACK	10	TAN	BLU-GRN

*Not allowed when security is ON

FACTORY FIVE '33 SYSTEM ASSIGNMENTS Ver 10.3

See www.isispower.com for standard Front Engine, Rear Engine, and Factory Five Racing GTM.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Rear Running Lights & LP Light	15	A	1	B	Track	6	YELLOW	YEL-GRN
Radio & Amplifier	16	A	2	A	Track	7	BLUE	TAN-BLK
Drivers Side Unlock	17	A	2	A	Track	8	GREEN	TAN-RED
Passenger Side Unlock	18	A	2	A	Track	9	ORANGE	TAN-BLU
Power Windows	19	A	2	A	Track	10	TAN	TAN-YEL
Brake Lights with 1-Filament Bulbs	25	B	2	B	Track: Brake Function	1&2	BROWN&VIOLET	PNK-BLK
Right Turn Signal for 1-Filament Bulbs	26	B	1:2	B	1-Filament Turn Signals	2:2	VIOLET:VIOLET	PNK-RED
Left Turn Signal for 1-Filament Bulbs	27	B	1:2	B	1-Filament Turn Signals	1:1	BROWN:BROWN	PNK-BLU
4-Way Flasher for 1-Filament Bulbs	28	B	1:2	B	Track: Pattern	1&2:1&2	BROWN&VIOLET BROWN&VIOLET	PNK-YEL
Interior Lights	29	B	2	B	Track	3	LIGHT-GREEN	PNK-GRN

FACTORY FIVE '33 SYSTEM ASSIGNMENTS Ver 10.3

See www.isispower.com for standard Front Engine, Rear Engine, and Factory Five Racing GTM.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Alternating Headlight Toggle	38	B	1	A:B	Alternating Headlight	5:7	WHITE:BLUE	TAN-ORG
Push Button Ignition/Start*	39	B	1	B	NODE EFI Start	3:4	LT-GREEN: LT-BLUE	TAN-GRN

OPTIONAL 3rd POWERCELL™ FACTORY FIVE '33 SYSTEM ASSIGNMENTS Ver 10.3

See www.isispower.com for standard Front Engine, Rear Engine, and Factory Five Racing GTM.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Open	20	A	3	B	Track	1	BROWN	TAN-GRN
Open	21	A	3	B	Track	2	VIOLET	GRN-BLK
Open	22	A	3	B	Track	3	LIGHT-GREEN	GRN-BRN
Open	23	A	3	B	Track	4	LIGHT-BLUE	GRN-BLU
Open	24	A	3	B	Track	5	WHITE	GRN-ORG
Open	33	B	3	A	Track	6	YELLOW	Lt BLU-YEL
Open	34	B	3	A	Track	7	BLUE	Lt BLU-GRN
Open	35	B	3	A	Track	8	GREEN	TAN-BLK
Open	36	B	3	A	Track	9	ORANGE	TAN-RED
Open	37	B	3	A	Track	10	TAN	TAN-BLU