

FACTORY FIVE RACING GTM STANDARD SYSTEM ASSIGNMENTS Ver 10.3
 See www.isispower.com for standard Front Engine and Rear Engine configurations.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Driver Door Release	1	A	1	B	NODE_Timed	3	LIGHT-GREEN	WHT-BLK
Passenger Door Release	2	A	1	B	NODE_Timed	4	LIGHT-BLUE	WHT-RED
Ignition*	3	A	2	B	TRACK	4	LIGHT-BLUE	WHT-BLU
Starter*	4	A	2	B	TRACK	5	WHITE	WHT-YEL
Headlights	5	A	1	B	Post_Timed Headlights:Soft Start	5	WHITE	WHT-GRN
Parking lights	6	A	1:2	A	TRACK	6:6	YELLOW:YELLOW	BLU-BLK
High beams	7	A	1	A	TRACK: SOFT-START	7	BLUE	BLU-RED
Interior Lights	8	A	1	A	NODE_THEATER_ TIMED	8	GREEN	BLU-Lt BLU
Horn	9	A	1	A	TRACK	9	ORANGE	BLU-YEL
Fan override or open	10	A	1	A	TRACK	10	TAN	BLU-GRN

**Not allowed when security is ON*

FACTORY FIVE RACING GTM STANDARD SYSTEM ASSIGNMENTS Ver 10.3
See www.isispower.com for standard Front Engine and Rear Engine configurations.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
HID Headlights	11	A	1	B	Post Timed Headlights	5	WHITE	YEL-BLK
Open	12	A	2	A	Track	7	BLUE	YEL-RED
Open	13	A	2	A	Track	8	GREEN	YEL-BLU
Open	14	A	2	A	Track	9	ORANGE	YEL-ORG
Open	15	A	2	A	Track	10	TAN	YEL-GRN
Brake Lights with Multifilament Bulbs & Mechanical Column	16	A	2	B	Track	3	LIGHT-GREEN	TAN-BLK
Right Turn Signal Multifilament Bulbs & Mechanical Column	17	A	1:2	B	Track Pattern: Turn Signal	2:2	VIOLET:VIOLET	TAN-RED
Left Turn Signal Multifilament Bulbs & Mechanical Column	18	A	1:2	B	Track Pattern: Turn Signal	1:1	BROWN:BROWN	TAN-BLU
4-Way Flasher Multifilament Bulbs & Mechanical Column	19	A	1:2	B	Track:Pattern	1&2:1&2	BROWN&VIOLET: BROWN&VIOLET	TAN-YEL
Brake Lights with 1-Filament Bulbs	20	A	2	B	Track: Brake Function	1&2	BROWN&VIOLET	TAN-GRN

FACTORY FIVE RACING GTM STANDARD SYSTEM ASSIGNMENTS Ver 10.3
See www.isispower.com for standard Front Engine and Rear Engine configurations.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Right Turn Signal for 1-Filament Bulbs	21	A	1:2	B	1-Filament Turn Signals	2:2	VIOLET:VIOLET	GRN-BLK
Left Turn Signal for 1- Filament Bulbs	22	A	1:2	B	1-Filament Turn Signals	1:1	BROWN:BROWN	GRN-BRN
4-Way Flasher for 1-Filament Bulbs	23	A	1:2	B	Track: Pattern	1&2:1&2	BROWN&VIOLET BROWN&VIOLET	GRN-BLU
One Button Start*	24	A	2	A:B	NODE_EFI_START	4:5	LIGHT BLUE:WHITE	GRN-ORG
Self Canceling Left Turn Signal	35	B	1:2	B	Self Canceling Turn Signal	1:1	BROWN:BROWN	TAN-BLK
Self Canceling Right Turn	36	B	1:2	B	Self Canceling Turn Signal	2:2	VIOLET:VIOLET	TAN-RED
4-Way Flasher with Self Cancelling Turn Signals	37	B	1:2	B	4-Way Flashers	1&2:1&2	BROWN&VIOLET BROWN&VIOLET	TAN-BLU
Brake Lights with Self-Canceling Turn Signals	38	B	2	B	Track:Brake Function	3	LT-GREEN	TAN-ORG
Alternating Headlight Toggle	39	B	1	A:B	Alternating Headlight	5:7	WHITE:BLUE	TAN-GRN
Alternating Headlight Toggle HID	40	B	1	A:B	Alternating Headlight HID	5:7	WHITE:BLUE	BRN-BLK

FACTORY FIVE RACING GTM STANDARD SYSTEM ASSIGNMENTS Ver 10.3
 See www.isispower.com for standard Front Engine and Rear Engine configurations.

Function	Switch Input	MASTERCELL™ Connector	POWERCELL™ Address	POWERCELL™ Connector	Personality	POWERCELL™ Output	POWERCELL™ Wire Color	MASTERCELL™ Wire Color
Open	25	B	3	B	Track	1	BROWN	PNK-BLK
Open	26	B	3	B	Track	2	VIOLET	PNK-RED
Open	27	B	3	B	Track	3	LIGHT-GREEN	PNK-BLU
Open	28	B	3	B	Track	4	LIGHT-BLUE	PNK-YEL
Open	29	B	3	B	Track	5	WHITE	PNK-GRN
Open	30	B	3	A	Track	6	YELLOW	Lt BLU-BLK
Open	31	B	3	A	Track	7	BLUE	Lt BLU-RED
Open	32	B	3	A	Track	8	GREEN	Lt BLU-BRN
Open	33	B	3	A	Track	9	ORANGE	Lt BLU-YEL
Open	34	B	3	A	Track	10	TAN	Lt BLU-GRN